

## Hybridize Oligo Pool

- 1 Add 5  $\mu$ l ACD1 to 1 well of the HYP plate.
- 2 Add 5  $\mu$ l gDNA to each remaining well.
- 3 Add 5  $\mu$ l ACP1 to the well containing ACD1.
- 4 Add 5  $\mu$ l AFP1 to each well containing gDNA.
- 5 Centrifuge at 1000  $\times$  g for 1 minute.
- 6 Add 40  $\mu$ l OHS1. Pipette to mix.
- 7 Centrifuge at 1000  $\times$  g for 1 minute.
- 8 Place on the preheated heat block and incubate for 1 minute.
- 9 Reset the temperature to 40°C and incubate for 80 minutes.

## Remove Unbound Oligos

- 1 Make sure that the heat block has cooled to 40°C.
- 2 Remove from the heat block.
- 3 Centrifuge at 1000  $\times$  g for 1 minute.
- 4 Transfer each sample to the FPU plate.
- 5 Cover and centrifuge at 2400  $\times$  g for 2 minutes.
- 6 Wash 2 times with 45  $\mu$ l SW1.
- 7 Reassemble the FPU plate.
- 8 Add 45  $\mu$ l UB1.
- 9 Cover and centrifuge at 2400  $\times$  g for 2 minutes.

## Extend and Ligate Bound Oligos

- 1 Add 45  $\mu$ l ELM3 to the FPU plate.
- 2 Incubate at 37°C for 45 minutes.

## Amplify Libraries

- 1 Arrange the Index 1 (i7) adapters in columns 1–12.
- 2 Arrange the Index 2 (i5) adapters in rows A–H.
- 3 Place the plate on a TruSeq Index Plate Fixture.
- 4 Add 4 µl of each Index 1 (i7) adapter down each column.
- 5 Add 4 µl of each Index 2 (i5) adapter across each row.
- 6 Remove the FPU plate from the incubator and do the following.
  - a Replace the aluminum foil seal with the filter plate lid.
  - b Centrifuge at 2400 × g for 2 minutes.
  - c Add 25 µl 50 mM NaOH. Pipette to mix.
  - d Incubate at room temperature for 5 minutes.
- 7 Add 56 µl TDP1 to a full tube (2.8 ml) of PMM2. Invert to mix.
- 8 Transfer 22 µl PMM2/TDP1 mixture to the IAP plate.
- 9 Transfer eluted samples from the FPU plate to the IAP plate.
- 10 Centrifuge at 1000 × g for 1 minute.
- 11 Transfer the IAP plate to the post-amplification area.
- 12 Place on the preprogrammed thermal cycler and run the PCR program.

## SAFE STOPPING POINT

If you are stopping, seal the plate and store at 2°C to 8°C for up to 2 days. Alternatively, leave on the thermal cycler overnight.

## Clean Up Libraries

- 1 Centrifuge the IAP plate at 1000 × g for 1 minute.
- 2 Run an aliquot of library and control on 4% agarose gel (5 µl) or Bioanalyzer (1 µl).
- 3 Add 45 µl AMPure XP beads to the CLP plate.
- 4 Transfer all the supernatant from the IAP plate to the CLP plate.
- 5 Shake at 1800 rpm for 2 minutes.
- 6 Incubate at room temperature for 10 minutes.
- 7 Place on a magnetic stand until liquid is clear.
- 8 Remove and discard all supernatant.
- 9 Wash 2 times with 200 µl 80% EtOH.
- 10 Use a 20 µl pipette to remove residual EtOH.
- 11 Remove from the magnetic stand and air-dry for 10 minutes.
- 12 Add 30 µl EBT.
- 13 Shake at 1800 rpm for 2 minutes.
- 14 Incubate at room temperature for 2 minutes.
- 15 Place on a magnetic stand until liquid is clear.
- 16 Transfer 20 µl supernatant from the CLP plate to the LNP plate.
- 17 Centrifuge at 1000 × g for 1 minute.

## Normalize Libraries

- 1 For 96 samples, add 4.4 ml LNA1 to a new 15 ml conical tube.
- 2 Use a P1000 pipette to resuspend LNB1.
- 3 Transfer 800 µl LNB1 to the tube of LNA1.
- 4 Add 45 µl LNA1/LNB1 to the LNP plate.
- 5 Shake at 1800 rpm for 30 minutes.
- 6 Place on a magnetic stand until liquid is clear.
- 7 Remove and discard all supernatant.
- 8 Remove from the magnetic stand.
- 9 Wash 2 times with 45 µl LNW1.
- 10 Use a 20 µl pipette to remove residual LNW1.
- 11 Remove from the magnetic stand.
- 12 Add 30 µl fresh 0.1 N NaOH.
- 13 Shake at 1800 rpm for 5 minutes.
- 14 Place the LNP plate on a magnetic stand until liquid is clear.
- 15 Add 30 µl LNS1 to the SGP plate.
- 16 Transfer 30 µl supernatant from the LNP plate to the SGP plate.
- 17 Centrifuge at 1000 × g for 1 minute.

## SAFE STOPPING POINT

If you are stopping, seal the plate and store at -25°C to -15°C for up to 30 days.

## Pool Libraries

- 1 Centrifuge at 1000 × g for 1 minute.
- 2 Transfer 5 µl of each library to an 8-tube strip.
- 3 Transfer the contents of the 8-tube strip to the PAL tube. Pipette to mix.
- 4 Denature and dilute pooled libraries to the loading concentration for the sequencing instrument you are using. See the denature and dilute libraries guide for your instrument.

## Acronyms

Acronym	Definition
ACD1	Amplicon Control DNA 1
ACP1	Amplicon Control Oligo Pool 1
AFP1	Amplicon Fixed Panel 1
CLP	Clean-up Plate
EBT	Elution Buffer with Tris
ELM3	Extension Ligation Mix 3
FPU	Filter Plate Unit
HT1	Hybridization Buffer
HYP	Hybridization Plate
IAP	Indexed Amplification Plate
LNA1	Library Normalization Additives 1
LNB1	Library Normalization Beads 1
LNS1	Library Normalization Storage Buffer 1
LNW1	Library Normalization Wash 1
LNP	Library Normalization Plate
OHS1	Oligo Hybridization for Sequencing Reagent 1
PAL	Pooled Amplicon Library
PMM2	PCR Master Mix 2

Acronym	Definition
SGP	Storage Plate
SW1	Stringent Wash 1
TDP1	TruSeq DNA Polymerase 1
UB1	Universal Buffer 1